

porter



technical information

- Use fast setting adhesives
- Apply sealers such as DRY TREAT during the installation process
- Use stone friendly grout and silicones

Installation should be completed using stone suitable fast setting adhesive or silicone to a flat, non-moisture sensitive substrate.

Upon installation, the stone should be sealed with appropriate stone sealer.

Please note that all products must be fabricated using score & snap method and/or wet cutting in conjunction with AS/NZS 1716:2012, AS/NZS 1715:2009, AS/NZS 60335.2.69:2017. For more information please refer to: <https://www.safework.nsw.gov.au>

Variation is an inherent property of tiles and stone. Sizes are nominal and may include a joint.

A 2/12-14 Neild Avenue Rushcutters Bay NSW 2010 | P 02 8755 2300 | W www.skheme.com | E info@skheme.com